

SKYvenetian GUIDEWIRE INSTALLATION

New Style Spring tensioned guidewire

1. Mount Venetian mounting brackets directly above guidewire holes or as close as possible. (as high wire tension is required).
2. If soft headliner consider using OA plastic spacer to enable lever of bracket to clear soft delicate fabrics – see picture below
3. Mount blind and fix position of GW hold down – must be at right angles and directly below guidewire hole in headrail. Fix one hold down then equally space second hold down using the headrail as the spacer.
4. Mount base fitting and Measure height between bottom of headrail and worktop surface. Put wire through cap knotting off one end first at the measured distance. Ensuring spring between guidewire is centrally positioned between any hardware in the headrail. **This is very important.**
5. On the second Guidewire take previous measurement and shorten by 15mm, put through cap and knot. This should give sufficient tension to stretch the spring and ensure both Guidewires are adequately tensioned. If insufficient tight shorten wire to suit. Wind both caps down flush with surface.

Guidewire fixings (brass or chrome)

